INSTRUCTIONS

FOR CARE AND USE

of

NICHOLL *Velvet Shaver*

IF VELVET SHAVING IS

New

TO YOU

The facts contained in this booklet will enable you to secure the fullest value from your NICHOLL VELVET SHAVER and the maximum of shaving comfort without the bother of brushes, blades, lather or soap. READ THESE DIRECTIONS CAREFULLY.

AMERICA'S FINEST ELECTRIC SHAVER

DIRECTIONS FOR USE

First, be sure your skin is clean and dry. Then plug the shaver into any ordinary electric outlet. Spin the starter disc with your forefinger and you are ready to shave.

Hold the shaver firmly against your skin at an angle of 45 degrees so that one side of the V-shaped head is flat against the skin, and so that you can feel the points at the tip. One side of the V-shaped head is for close shaving, the other for light shaving. The close side is recommended for the face, and the light side for the neck and for feminine use.

The shaver should be moved forward and backward with short, firm movements, with and against the direction of hair growth. Emphasis should be on the "against" stroke. In some instances it is well to draw skin taut with fingertips in the direction against beard growth to secure an even closer shave.



You may find it helps, at first, to let the beard grow unusually long before shaving so as to see more easily the exact direction of your whisker growth. With practice, you will soon have the "feel" of the VELVET SHAVER, and as the scar-tissue caused by continuous blade scraping disappears, your shaves will be faster and closer.

IMPORTANT

1. Have skin clean and dry for shaving.
2. Hold shaver at proper angle.
3. Draw skin in direction opposite beard growth.
4. Shave against and with growth, emphasizing former.
5. Use short, firm strokes in shaving.

Small pl
tion for
McCHOLL VERI-FI SHAVER
Set screw for detaching shaving head.
Spin to right with finger to start.
V-shaped head, light shaving side.
These grooves should be of same end.

OIL HEAD AT REGULAR INTERVALS.

Push the inner cutter part way out as shown below and place a small amount of light oil on the base and sides of the inner cutter. Then push the other end part way out and repeat oiling. Do not oil the motor.



FEMININE USE

The side of the V-shaped head marked with the trade name "Nicholl Velvet Shaver" is the side for feminine use. For shaving under-arms or legs, move the shaver forward against the direction of hair growth using 2 or 3 inch strokes. Dust the under-arms with talcum so as to absorb moisture before shaving. Shave as often as you wish with the VELVET SHAVER. It will not increase or coarsen the hair, nor will it irritate the skin.

SKIN CONDITIONING

Use of a blade razor cuts and scrapes the surface of the face, causing a layer of scar tissue to be formed. The regular use of the VELVET SHAVER gradually eliminates this scar condition and the skin returns to a healthy, normal bloom. During this transition period, you may experience difficulty in securing as close a shave as you may wish, but do not use a blade razor during this time. To do so will postpone the fast, smooth shaves that only a VELVET SHAVER can give your face because one blade shave will re-establish part of the scar tissue.

SERVICE AND CONSTRUCTION

The shaving head should be lubricated about once a week with any light oil. Remove the head by loosening set screw and push inner cutter out. Oil the base and sides of the inner cutter but not the shearing edges. Replace inner cutter so groove at one end is in line with groove in outer cutter as shown in diagram. See that the head is properly seated before tightening the set screw. Clean the head after each shave by passing the cleaning brush through the opening. Don't expect satisfactory results from a dirty shaving head.

DO NOT OIL THE MOTOR as it is equipped with oilless bearings and needs no attention. It is characteristic of the type of motors used in electric shavers to run at two speeds. If you find your motor running slowly and desire greater speed, give it a brisk shake. The shaver will cut equally well at either speed.

If the motor is cold it may run unevenly on the start. If this occurs, give the motor about a minute to warm up, and it will attain its regular speed.

GUARANTEED IN WRITING

Your NICHOLL VELVET SHAVER carries a one year guarantee against defective parts, and the factory will repair or replace any part proving defective within the period of the guarantee provided the registration slip is detached from guarantee blank and mailed to the manufacturer. This naturally does not cover damage by accident or abuse. Mail registration to NICHOLL, INC., 766 East 12th Street, Los Angeles, Calif.



AMERICA'S FINEST ELECTRIC SHAVER

PRINTED IN U.S.A